



WKL 1-SERIES WORK LIGHT

INSTALLATION INSTRUCTIONS



For use with:

Model #	Input Voltage	Wattage
WKL1-304-1	100-240V	30W
WKL1-504-1	100-240V	50W

WHAT'S IN THE BOX

- LED WORK LIGHT FIXTURE w/ 10 FOOT LONG CORD

WHAT YOU'LL NEED

- AVAILABLE ELECTRICAL RECEPTACLE ON JOBSITE

WARNING

- Turn off the power when you perform any maintenance.
- Verify that the receptacle voltage is correct before plugging in the fixture.
- Keep lens tightly closed when in operation.
- Modifications to the product voids the warranty.

Failure to heed these warnings may result in personal injury or property damage.

IMPORTANT

Before assembling your PREMISE LED fixture, please make sure that you carefully read through this instruction sheet.

Note: The important safeguards and instructions that appear in this sheet are not meant to cover all possible conditions and situations that may occur. It must be understood that common sense, caution, and care are factors that cannot be built into any product. These factors must be supplied by the person(s) caring for and operating the fixture.

PREMISE LED Inc.
80-86 Carrier Drive
Toronto, ON Canada
M9W 5R1
PREMISELED.COM

INSTALLATION OPTIONS

The WKL1-Series Work Lights include a 10 foot cord for plugging into 100-240VAC receptacles.

Optionally, they can be affixed to:

Tripod (PAL1-TP)

Heavy-duty Hook (WKL1-HOOK)

Both accessories are available separately from Premise LED.

Note that the Tripod can accommodate:

2 x WKL1-304-1 or 1 x WKL1-504-1



WKL1-HOOK




PAL1-TP

OPERATING THE WORK LIGHT

1. Use the integrated handle to transport the fixture.
2. To turn the fixture on, plug in the work light into compatible receptacle.
3. To turn the fixture off, unplug the work light from the receptacle.

TO INSTALL THE OPTIONAL HOOK

1. The Hook includes a customized u-bracket.
2. Unfasten the existing U-bracket on the work light.
3. Align the holes of the customized u-bracket (included with your hook), fasten and tighten it onto the work light.
4. Ensure that the screw is fastened tightly on the u-bracket.
5. Hang the work light in the desired position, and tighten the safety screw.



TO INSTALL THE OPTIONAL TRIPOD

1. Unfasten the existing floor stand bracket from the u-bracket on the work light.
2. Align the holes of the work light's u-bracket with the holes of the tripod's mounting plate, then fasten and tighten it the work light onto the tripod.
3. Ensure that the screw is fastened tightly onto the tripod.

